

Netgear WGT624V4 Router Wireless or Wired



DLINK EBR2310



ComSpan may install a router between the Switch/Hub and your computer to isolate your computer from the rest of the network. This may improve TV quality as well as internet speeds and reliability of both services.

As the Router is a powered piece of equipment, it may need to be power cycled (re-booted) at times. If you are unable to connect to the internet or are experiencing slow speeds as part of the troubleshooting process you should reboot the router. You may accomplish this by removing the power cord from the back of the unit, wait 1 minute and then plug the power cord back into the unit. The unit's can take 3-5 minutes to fully reboot. Once all lights are solid please try to access a web page. If all troubleshooting has been completed and you are still experiencing problems please call ComSpan Customer Support at 866-535-9858.