

Understanding your Netgear Desktop Switches



You have now received a Netgear switch during the installation of your services. Periodically the switch may need to be power cycled. (Re-booted) To power cycle a switch the unplug power to the switch, wait 1-2 minutes and then reattach the power to the switch. Lights will appear flickering on all used ports on the switch. Then you may then attempt to view a web page. If you cannot connect to any web page, please call Comspan Customer Support at 866-535-9858.